

## Puncture Instruments Trocars



**Standard (Nelson)**

| Ømm | 11cm/4½"    |
|-----|-------------|
| 3.0 | 11-01112-30 |
| 3.5 | 11-01112-35 |
| 4.0 | 11-01112-40 |
| 4.5 | 11-01112-45 |
| 5.0 | 11-01112-50 |
| 5.5 | 11-01112-55 |
| 6.0 | 11-01112-60 |



**Standard (Nelson)**

| Ømm | 12cm/4¾"    |
|-----|-------------|
| 3.0 | 11-01116-30 |
| 3.5 | 11-01116-35 |
| 4.0 | 11-01116-40 |
| 4.5 | 11-01116-45 |
| 5.0 | 11-01116-50 |
| 5.5 | 11-01116-55 |
| 6.0 | 11-01116-60 |



**Standard (Nelson)**

| Ømm | 12cm/4¾"    |
|-----|-------------|
| 3.0 | 11-01120-30 |
| 3.5 | 11-01120-35 |
| 4.0 | 11-01120-40 |
| 4.5 | 11-01120-45 |
| 5.0 | 11-01120-50 |
| 5.5 | 11-01120-55 |
| 6.0 | 11-01120-60 |



**Universal**

11-01124-03 =3 Set of 3  
11-01124-04 =4 Set of 4



Ø6



4 ½



3



1¾ mm



**Universal**

11-01128-03 =3 Set of 3  
11-01128-04 =4 Set of 4