
















Kocher
21.5cm/8½"

		15x10 mm	15x15 mm	15x20 mm	15x30 mm	15x40 mm
sharp						
	17-05295-01	17-05295-02	17-05295-03	17-05295-04	17-05295-06	17-05295-08
blunt						
	17-05296-01	17-05296-02	17-05296-03	17-05296-04	17-05296-06	17-05296-08
semi-sharp						
	17-05297-01	17-05297-02	17-05297-03	17-05297-04	17-05297-06	17-05297-08




sharp

17-5301-20
20 cm/8"



blunt

17-5302-20
20 cm/8"



sharp

17-5305-14
14 cm/5½"