



**Kocher**  
19 cm/7½"

19-06664-01

19-06664-02

19-06664-03



**Kronecker**  
19-06672-01 13 cm/5" 19-06672-02



**Dupuy-Weiss**  
19-06677-01 22 cm/8¾" 19-06677-02



**Durham**  
19-06685-01 21 cm/8¼" 19-06685-02