













Handle



Tip with tube

**Townsend**

		Complete instrument	Tip, only
	<b>Tischier</b>	27-09152-00	27-09152-01
	<b>Kevorkian</b>	27-09154-00	27-09154-01
	<b>Mini-Townsend</b>	27-09156-00	27-09156-01
	 <b>Tischler-up</b>	27-09158-00	27-09158-01
	 <b>Tischler-down</b>	27-09160-00	27-09160-01
	<b>Mini-Townsend-up</b>	27-09162-00	27-09162-01
	 <b>Mini-Townsend-down</b>	27-09164-00	27-09164-01